



BOSTONIAN SHOWER SYSTEM

INSTALLATION INSTRUCTIONS

Before installing, read entire Bostonian Shower System Installation Instructions. Observe all local building and safety codes.

For the following installation instructions it is assumed that the water supply lines have been installed in the desired location behind the finished wall and are accessible for shower installation.

Unpack and inspect the product for any shipping damages. If you find damages, do not install. Contact Customer Service at 1-866-855-2284. If you need assistance or have questions while installing your shower, contact Customer Service.

We recommend consulting a professional if you are unfamiliar with installing bathroom fixtures. Signature Hardware accepts no liability for any damage to the floor, walls, plumbing or for personal injury during installation.

TOOLS AND MATERIALS:

Silicone Sealant

Level

Thread Sealant or Teflon Tape

INSTALLATION

1. Place thread sealant, or Teflon tape, on the threaded portions of the included ½" pipe nipple. Thread the pipe nipple into the fitting at the finished wall.

NOTE: If your pipe nipple is already attached, please proceed directly to step 3.

2. Unthread to remove the water supply tee from the shower riser pipe. This can be found at the top of the riser pipe, where the pipe pivots slightly
3. Place the decorative escutcheon on the water supply tee, and attach the tee to the pipe nipple at the finished wall.
4. Reattach the riser pipe to the supply tee. Do not fully tighten the connecting nut.
5. Remove the back from the piece of double-sided tape on the back of the handle tee.
6. Hold the shower out slightly from the wall. Use a level to verify that the riser pipe is completely straight.
7. When the riser is aligned properly, gently press the handle tee into the wall.
8. With the included Allen wrench, remove the small set screw from the underside of the handle tee. This will release the mounting bracket that is being held in place by the double-sided tape.
9. Gently pull the riser pipe out from the wall. The mounting bracket should be fixed in the mounting location.
10. Push the riser pipe aside and attach the bracket to the wall with the appropriate mounting hardware.
11. Place the decorative escutcheon on the handle tee and gently put the riser pipe back in place over the mounting bracket. Reinsert the set screw to secure.



12. Tighten the connecting nut at the base of the water supply tee.
13. Attach the shower arm to the top of the riser pipe. Do not tighten more than $\frac{1}{4}$ turn beyond hand tight.
14. Assemble the hand shower and hose, and attach the hose to the outlet at the bottom of the handle tee.
15. Turn on the water supply and open the faucet valves. Check for any leaks and verify that the hot and cold supplies are working correctly. Let the water flow through the riser pipe and hand shower hose for approximately 30 seconds to clear out debris and dirt.

Note: If leakage occurs, tighten connections with an adjustable wrench as necessary. If problems persist, contact Customer Service at 1-866-855-2284.