



FELICITY WALL-MOUNT FAUCET

Before installing, read entire Installation Instructions. Observe all local building and safety codes.

For the following installation instructions for your new wall-mount faucet it is assumed that any old fixtures have been removed and the water supply lines are in place. Two ½" pipe nipples should be attached to the water supply lines and accessible for installation.

Unpack and inspect the product for any shipping damages. If you find damages, do not install. Contact Customer Service at 1-866-855-2284. If you need assistance or have questions while installing your faucet, contact Customer Service.

We recommend consulting a professional if you are unfamiliar with installing kitchen fixtures. Signature Hardware accepts no liability for any damage to the floor, walls, plumbing or for personal injury during installation.

Turn off the water supply at the sink where the new faucet is being installed.

TOOLS AND MATERIALS:

Thread Sealant or Plumber's Tape

Silicone Sealant

Damp Cloth

INSTALLATION

1. Remove the 90° wall couplers from the faucet body.
2. Place thread sealant or plumber's tape on the ½" pipe nipples.
3. Run a bead of silicone sealant along the base of the wall couplers.
4. Thread the wall couplers onto the ½" pipe nipples.
5. Make sure the bases of the couplers are firmly against the wall and that the couplers are aligned properly. Wipe away any excess sealant with a damp cloth.
6. Place the faucet body on the wall couplers. Hand tighten the coupling nuts to secure.
7. Install the side spray hose and nozzle if included.
8. When your faucet installation is complete, turn on the water supply. Check to make sure that all connections are tight (no water should be leaking) and that the hot and cold supplies are working correctly. Turn the water on and allow the water to flow through the spout for approximately 60 seconds. If you have a side spray, divert the water to the spray and allow the water to flow through the hose for an additional 60 seconds.