



GATE RIM LATCH AND HANDLE SET

INSTALLATION INSTRUCTIONS

Before installing, read entire Gate Rim Latch Installation Instructions. Observe all local building and safety codes. For the following installation instructions it is assumed that any old fixtures have been removed and any repairs to the gate have been completed.

Unpack and inspect the product for any shipping damages. If you find damages, do not install. Contact Customer Service at 1.866.855.2284. If you need assistance or have questions while installing your latch contact Customer Service.

We recommend consulting a professional if you are unfamiliar with installing hardware fixtures. Signature Hardware accepts no liability for any damage to the gate or latch, or for personal injury during installation.

TOOLS AND MATERIALS:

Drill	Screwdriver	Chisel
Safety glasses	Pencil	Sandpaper

INSTALLATION

- 1. Assemble the gate rim latch body.** Unscrew the bolt knob and slide the bolt through the bolt guide. Reattach the bolt knob.
- 2. Decide where to position the handle and gate rim latch body.** With the gate in the closed position, determine the position of the handle on the outside of the fence and latch body on the inside of the fence. Typically the latch body is affixed to a horizontal beam near the top of the gate. Ideally, the thumb lever of the handle will lift the bolt about midway between the bolt knob and the catch. Mark the positions of the latch bolt screw holes on the inside of the fence.
- 3. Cut out a slot for the thumb lever.** Hold the latch body in position and use a pencil to mark just below the bolt, about midway between the bolt knob and the catch. Drill two 1/2" diameter holes above and below the mark, and chisel out the area in between. Smooth with sandpaper, if needed.
- 4. Affix the thumb lever.** On the outside of the gate, insert the thumb lever through the cut-out slot and rest it lightly on the bottom edge of the hole. Affix the thumb lever to the gate with the screws provided.
- 5. Affix the latch body.** Affix the latch body to the inside of the gate with the screws provided, making sure that thumb lever will lift the bolt.
- 6. Affix the catch to the fence post.** Affix the catch to the fence post with the screws provided, making sure that the bolt will rest in the catch.

